



Made 2 Measure Factory Assemble Knock Down System Vertical Tube

Balustrades

Material Guide



1 Determine the Railing Materials you'll need to Complete your project. Follow steps A, B, C, and D.

A Measure the area where the railing is to be installed.

B Determine the Quantity of Posts needed.


C Determine the Quantity of Top rail & filler's needed.

D Determine the Quantity of Sleeves for Top Rail Post Assembly needed.



2 Once you've made your selection, use the item codes below to add the items to your shopping cart.

Now select your Vertical Tube Railing Posts




2x Posts

Code: V.007.STR

Vertical Straight

End Post Set




2x Posts

Code: V.007.STA


Vertical Stair

End Post Set



Code: V.007.180

180° Joining Post



Code: V.007.90

90° Corner Post

Next, Select your 3m Panel Filler (in-fill) Straight or Stair



Code: V.007.P.STR

3m Vertical Straight Panel


Vertical Tube Knock Down System

Balustrades



Material Guide

Now select your Straight Vertical Tube Railing Posts

Start & End Posts



Straight




Code: V.007.STR

Vertical Straight

End Post Set

Now select your Stair Vertical Tube Railing Posts

Start & End Posts




Stair

NB: Accommodates

Any Stair Angle

Straight section



Code: V.007.STA

Vertical Stair

End Post Set

Vertical Tube Knock Down System

Balustrades

1m High Posts

Material Guide

Now select your 180° Joining Post Vertical Tube Railing Posts




180° Joining Post

Code: V.007.180

NB: Accommodates

Any Stair Angle

Straight section



Now select your 90° Corner Post Vertical Tube Railing




90° Corner Post

Code: V.007.90

NB: Accommodates

Any Stair Angle

Straight section




Vertical Tube

Balustrades

1m High Posts

Material Guide


Finally, Select your Rolled 3m Panel Filler (in-fill)



Code: V.007.P.STA.R

3m Vertical Rolled Panel

Finally, Select your Straight 3m Panel Filler (in-fill)



Code: V.007.P.STR

3m Vertical Straight Panel



Vertical Tube Balustrades Material Guide 1m High Posts

Select your Post Fix Options

Substrate

- Concrete
- Steel
- Wood
- Composite
- Glass



Substrate

Tread Fixing

Flange Fix

Side Fix

Top Fix



Top Fix



Concrete



Wood



M16/ M12 Stud Post Fixing

Threaded stud supplied separately



Sikadur Epoxy adhesive AP



M12x75

